

Farr 30 Tuning Guide

Base Settings:	
Headstay Pin to Pin Measurement:	12140mm
Rake: Swing Arc - Use Centerline halyard pulled down to top of black band - pull forward to mark headstay.	
Mark on headstay down to headstay pin:	1820mm
Cap Shroud Tension:	#35 on RT 10 Rod Loos Gauge
D1 Tension:	#10 on PT2 Wire Loos Gauge
D2 Tension:	#7 on PT2 Wire Loos Gauge
J Dimension:	3315mm
Mast Base - (Distance from forward headstay bolt to front of mast):	3480 mm
Pre-Bend:	75mm

Quick Adjustments (full turns from base settings)					
True Wind Speed:	Sail Selection:	Headstay:	Cap Shrouds:	D1s:	D2s:
Really light (0-5k)	Light Jib/ Masthead Light spin /Masthead A spin	-10	-2	-2	Base
Light (5-9k)	Light Jib / Masthead Light spin	-7	-1	-1	Base
Medium (10-15k)	Medium Jib/ Masthead Light spin	Base	Base	Base	Base
Heavy (16-20k)	Medium Jib / Masthead Heavy spin	+7	+1	+2	Base
Really Heavy (21k+)	Heavy Jib / Masthead Heavy spin	+15	+2	+3	+2